

# Piccolo Dry Canister Vacuum

## Table of Contents

Technical Information & Safety	Page	3, 4
Preparation & Operation	Page	5
After Use & Maintenance	Page	5
Part Schematic	Page	6, 7

## Piccolo Dry Canister Vacuum

### Technical Information

Tank Size	2-Gallon
Vacuum Motor	1.6 hp (1-stage direct)
Noise Level	61 dB
Filtration	Triple (Bag, cartridge & exhaust)
Airflow	105 cfm
Water Lift	115"
Power Cord	50'
Length	15.5"
Width	13"
Height	15.5"
Weight	15 lbs
Tool Kit	Included
Productivity	2,700 sq. ft./hour

# Piccolo Dry Canister Vacuum

## General Safety Information

When using an electrical appliance, basic precautions should always be followed, read all instructions before using.

### **! WARNING! To reduce risk of fire, electric shock, or injury:**

- Do not leave the machine when it is plugged in. Unplug the unit from the outlet when not in use & before servicing.
- To avoid electric shock, do not expose machine to rain. Store indoors.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If machine is not working as it should return it to a service center for inspection.
- Do not pull or carry by cord, use cord as a handle, close a door on a cord, or pull cord around sharp edges or corners. Do not run machine over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or machine with wet hands.
- Do not put any foreign object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, & anything that may reduce airflow.
- Keep hair, loose clothing, fingers, & all parts of body away from openings & moving parts.
- Turn off all controls before unplugging.
- Do not use in or around flammable or combustible liquids such as gasoline or use in areas where they may be present.

## Grounding Instructions

This machine must be grounded. If it should electrically malfunction, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with a cord having an equipment-grounding conductor & grounding plug. The plug must be plugged into an appropriate outlet that is properly installed & grounded in accordance with all local codes & ordinances.

### **! DANGER !**

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the machine. If plug will not fit the outlet, have a proper outlet installed by a qualified electrician.

Replace the plug if the grounding pin is damaged or broken.

Extension cords connected to this machine should be 12 gauge, 3-wire cords with 3-prong plugs & outlets. DO NOT use extension cords more than 50 feet long.

## Piccolo Dry Canister Vacuum

### **Preparation and Operation**

Unwrap the power cord completely & plug into a properly grounded outlet.

Install paper filter bag.

Attach swivel hose connector and hose to tank inlet.

Attach appropriate cleaning tool.

Turn switch to on position.

You are now ready to begin your cleaning task.

### **After Use**

Unplug the power cord, starting from the machine wrap the power cord onto the head assembly.

Check paper filter, replace as necessary.

Wipe the entire machine with a clean, damp cloth.

Inspect the machine & all accessories for damage. Perform any required maintenance or repairs before storage.

Store the machine in a clean, dry place.

<b>View#</b>		<b>SKU</b>	<b>Vacuum Head Parts</b>
4		36033	Intake Reducer
8		98002	Button Latch Lever
9		98003	Spring Latch Pin
10		98001	Handle
11		60002	Screw
12		98004	Grey Cover
13		98005	Plastic Cover Gasket
14		98006	Plastic Tank
15		60002	Screw
16		98042	Tank Intake Hose Connector
17		60037HV	Upper Motor Gasket
18		60025HV 110V	Motor 115 Volt
19		98010	Rubber Switch Cover
20		98012	Indicator Light
21		98016	Motor MountHV
22		98015	Switch holder
23		10025	Screw
24		60010	Screw
25		40506	Cable Strain Reliever
26		60004	Flex Cord Stop
27		600106/7	50' Power Cord
28		98021	Piccolo Board
29		98024	Axle Cap
30		98017	Rear Transport Wheel
31		98023	Axle
32		35002	Front Swivel Caster
33		60002	Screw
34		98007	Bottom Mount Plate
35		98022	Wireing
36		98011	Switch
37		98013	DEP. Switch T .200MM
38		60002	Screw
39		98027	Sponge Filter
41		98020	Exhaust Filter Standard
42		98014	Filter Cage
		<b>SKU</b>	<b>Tools and Filters</b>
1		36042	Extension Wand
2		36036	Crevice Tool
3		36035GR	Carpet & Hard Floor Brush Tool
5		36032A	Wand Handle
6		36037	Upholstery Tool
7		36043	Hose
43		98019/10	Paper Bag pkg. 10
44		98009/hepa	Hepa Cartridge Filter
44		98009	Cartridge Filter
45		36038	Dust Tool